



Original	Recharge
Open/Close	Eject / Surround
Power	Power
VCR	Shift + 4
DVD	Shift + 2
TV / VCR	TV/Radio /
TV / View	Smart / List
2	2
4	4
1 / Tracking -	1
5	5
3 / Tracking +	3
6	6
7	7
8	8
9	9
Clear	Exit / Cancel / Clear
0	0

Original	Recharge
P.Scan	Blue / Prime Video / Random
Menu	Menu / Home
Setup	Setup / OPT /
Up	Up
PR+	CH+ / Page+
PR-	CH- / Page-
Down	Down
Left	Left
Right	Right
Enter	OK
Edit	Fav / Marker / PC
Display	Display / Media
I<<	I<< / Preset-
>>I	>>I / Preset+
Pause	Pause / Step / Freeze
Play	Play / Slow
<<	<< / Tune-





Original		Recharge	
	>>		>> / Tune+
	Stop		Stop / Hold
	Rec		Rec / Rec Mode
	Input		AV / Input / RDS
	Subtitle		Subtitle / EQ
	< / Slow -		Vol-
	Slow + / >		Vol+
	Copy		Guide / EPG / -/--
	Angle		Info / Angle
	Rec Speed		Shift + Rec / Rec Mode
	Zoom		Zoom / Size
	Repeat		Green / APP / Repeat
	A-B		Yellow / YouTube / Repeat
	Search		Red / Netflix / Search
	Audio		Audio / Lang I/II
	Title		Sound / Title
	Timer		Sleep / Timer

Original		Recharge	





Original	Recharge
Open/Close	Eject / Surround
Power	Power
VCR	Shift + 4
DVD	Shift + 2
TV / VCR	TV/Radio /
TV / View	Smart / List
2	2
4	4
1 / Tracking -	1
5	5
3 / Tracking +	3
6	6
7	7
8	8
9	9
Clear	Exit / Cancel / Clear
0	0

Original	Recharge
P.Scan	Blue / Prime Video / Random
Menu	Menu / Home
Setup	Setup / OPT /
Up	Up
PR+	CH+ / Page+
PR-	CH- / Page-
Down	Down
Left	Left
Right	Right
Enter	OK
Edit	Fav / Marker / PC
Display	Display / Media
I<<	I<< / Preset-
I>>	I>> / Preset+
Pause	Pause / Step / Freeze
Play	Play / Slow
<<	<< / Tune-





Original	Recharge
 >>	 >> / Tune+
 Stop	 Stop / Hold
 Rec	 Rec / Rec Mode
 Input	 AV / Input / RDS
 Subtitle	 Subtitle / EQ
 <I / Slow -	 Vol-
 Slow + / I>	 Vol+
 Copy	 Guide / EPG / -/--
 Angle	 Info / Angle
 Rec Speed	 Shift + Rec / Rec Mode
 Zoom	 Zoom / Size
 Repeat	 Green / APP / Repeat
 A-B	 Yellow / YouTube / Repeat
 Search	 Red / Netflix / Search
 Audio	 Audio / Lang I/II
 Title	 Sound / Title
 Timer	 Sleep / Timer

Original	Recharge

