






























































































Original	Rechange
 Power	 Power
 TV	 TV/R
 Q.Menu	 Menu
 Picture	 Format
 Sound	 Shift + Dual
 Input	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 List	 List

Original	Rechange
 Q.View	 D. Menu
 FAV	 Pre Ch
 I/II	 Dual
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Page+	 Ch +
 Page-	 Ch -
 Time	 Shift + AV
 Reveal	 Media
 Update	 Subt
 Settings	 Options
 Hold	 Smart
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left





Original		Rechange		Original		Rechange	
	OK		Ok				
	Back		Back				
	Exit		Exit				
	Text		Text				
	Stop		Stop				
	<<		<<				
	Index		Info				
	Play		Play				
	Pause		Pause				
	>>		>>				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				

