




Original	Recharge	Original	Recharge
 Power	 Power	 Play Mode / Tuning Mode	 Shift + Play
 Display	 Info	 Bass Boost	 Subt
 Timer Menu	 Menu	 Return	 Back
 Sleep	 Sleep	 Repeat	 Text
 Audio In Function	 Red	 Volume+	 Vol +
 FM Function	 Green	 Volume-	 Vol -
 CD Function	 Yellow	 Up/Folder+	 Up
 USB Function	 Blue	 Down/Folder-	 Down
 EQ	 Dual	 Right	 Right
 FM Mode	 TV/R	 Left	 Left
 1 Tuner Memory Number	 1	 OK	 Ok
 2 Tuner Memory Number	 2	 I<</Preset-	 I<<
 3 Tuner Memory Number	 3	 Pause	 Pause
 4 Tuner Memory Number	 4	 >>I/Preset+	 >>I
 5 Tuner Memory Number	 5	 <</Tuning-	 <<
 6 Tuner Memory Number	 6	 Play	 Play
 Tuner Memory	 Guide	 >>/Tuning+	 >>



