








































Original		Rechange		Original		Rechange	
	Power		Power		Mute		Mute
	3D		3D		P+		Ch +
	TV		TV/R		P-		Ch -
	1		1		Info		Info
	2		2		YouTube		Media
	3		3		Smart Tv		Smart
	4		4		Guide		Guide
	5		5		Menu		Menu
	6		6		Back		Back
	7		7		Up		Up
	8		8		Down		Down
	9		9		Right		Right
	0		0		Left		Left
	Eco		Shift + 3D		OK		Ok
	Source		AV		Exit		Exit
	Vol+		Vol +		Option		Options
	Vol-		Vol -		Zoom+		Shift + Ch +





Original		Rechange		Original		Rechange	
	Zoom-		Shift + Ch -		<<		<<
	Sleep		Sleep		Rec		Rec
	PRE-CH		Pre Ch		>>		>>
	FAV		Shift + Pre Ch				
	List		List				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	O)/Lang		Dual				
	Subtitle		Subt				
	Text		Text				
	I<		I<<				
	Stop		Stop				
	Play		Play				
	Pause		Pause				
	>I		>>I				

