





















































| Original | Rechange |
|--|---|
|  Power |  Power |
|  Sleep |  Sleep |
|  Mute |  Mute |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  -/-- |  Shift + Guide |
|  Recall |  Back |
|  Source |  AV |
|  P.Std |  Format |

| Original | Rechange |
|--|--|
|  S.Std |  Dual |
|  Menu ATV |  Menu |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  OK |  Ok |
|  Vol + |  Vol + |
|  Vol - |  Vol - |
|  Program + |  Ch + |
|  Program - |  Ch - |
|  Freeze / Eject |  Eject |
|  Info / Display |  Info |
|  Menu DVB |  D. Menu |
|  I / II |  Shift + Dual |
|  TTX / Play / Pause |  Text |
|  TTX / Play / Pause |  Play |





| | Original | Rechange | Original | Rechange |
|---|-------------|---|----------|----------|
|  | Exit / Stop |  | | |
|  | Exit / Stop |  | | |
|  | EPG / Title |  | | |
|  | FAV |  | | |
|  | TV / R |  | | |
|  | Sub |  | | |
|  | Aspect |  | | |
|  | Mix / A-B |  | | |
|  | Red |  | | |
|  | I<< |  | | |
|  | Green |  | | |
|  | >>I |  | | |
|  | Yellow |  | | |
|  | << |  | | |
|  | Blue |  | | |
|  | >> |  | | |

