



Original	Rechange
 Source	 AV
 List	 List
 Teletext	 Text
 Guide/EPG	 Guide
 Info	 Info
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Setup	 Options
 Menu/Disc	 Menu
 Display	 Shift + Info
 Options	 Shift + Options
 Up	 Up
 Down	 Down
 I<<	 I<<
 I<<	 Left

Original	Rechange
 Play/Pause	 Ok
 Play	 Play
 Pause	 Pause
 >>I	 >>I
 Stop	 Stop
 >>I	 Right
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6





Original		Rechange		Original		Rechange	
	7		7				
	8		8				
	9		9				
	0		0				
	Return		Back				
	A-B/Repeat		Shift + Text				
	Subtitle		Subt				
	Audio		Dual				
	Angle		TV/R				
	[<>]		Format				

