












































































Original		Rechange		Original		Rechange	
	Standby		Power		8		8
	Mute		Mute		9		9
	P.Mode		Shift + Format		0/10		0
	S.Mode		Shift + Dual		-/--/+10		Guide
	Aspect		Format		Recall/Program		Pre Ch
	Sleep		Sleep		Menu		Menu
	TTX		Text		Source		AV
	Index		List		i/Display		Info
	Subtitle		Subt		Exit		Exit
	Audio/I-II		Dual		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Vol+		Vol +
	6		6		Vol-		Vol -
	7		7		CH+		Ch +





Original		Rechange		Original		Rechange	
	CH-		Ch -		I<<		I<<
	Red/D.Setup		Red		>>I/FAV		>>I
	Green/D.Menu		Green				
	Yellow/T.List/Title		Yellow				
	Blue/R.List/D.Display		Blue				
	Open/Close/Mix		Eject				
	Goto/Hold		Media				
	A-B/Reveal		Options				
	Zoom/Size		Shift + Eject				
	Subpage		Back				
	Tv/Radio		TV/R				
	Rec/Repeat		Rec				
	Stop		Stop				
	Play		Play				
	Pause		Pause				
	<</List		<<				
	>>		>>				

