







































































Original	Recharge	Original	Recharge
	On		Power
	Off		Shift + Power
	Rec		Rec
	Pause		Pause
	Stop		Stop
	<<		<<
	Play		Play
	>>		>>
	I<		I<<
	>I		>>I
	←		Pre Ch
	TV		TV/R
	(i)		Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	CH+		Ch +
	CH-		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	*		Smart



