




Original	Recharge	Original	Recharge
 Power	 Power	 Play	 Play
 Sleep	 Sleep	 Pause	 Pause
 CD	 1	 >>I	 >>I
 iPod	 2	 I<<	 I<<
 AUX	 3	 Stop	 Stop
 Tuner	 4	 Option	 Options
 USB	 6	 Back	 Back
 Folder Down	 Ch -	 X	 Media
 Folder Up	 Ch +	 Display	 Info
 ←	 <<	 Vol+	 Vol +
 →	 >>	 Vol-	 Vol -
 Up	 Up	 Mute	 Mute
 Down	 Down	 Red	 Red
 Right	 Right	 Green	 Green
 Left	 Left	 Yellow	 Yellow
 Enter	 Ok	 Memory	 TV/R
 Menu	 Menu	 Preset >	 Blue

Original	Recharge	Original	Recharge
 Play	 Play	 Play Mode	 Play Mode
 Pause	 Pause	 >>I	 >>I
 >>I	 >>I	 I<<	 I<<
 I<<	 I<<	 Stop	 Stop
 Option	 Options	 Back	 Back
 Back	 Back	 X	 Media
 Display	 Info	 Vol+	 Vol +
 Vol+	 Vol +	 Vol-	 Vol -
 Vol-	 Vol -	 Mute	 Mute
Mute	Mute	Red	Red
Red	Red	Green	Green
Green	Green	Yellow	Yellow
Yellow	Yellow	Memory	TV/R
Memory	TV/R	Preset >	Blue
Preset >	Blue		

