






















































Original	Recharge	Original	Recharge
 Power	 On	 HDMI Link	 9 / HDMI
 Vol+	 Vol +	 Link Menu	 Shift + Menu /
 Vol-	 Vol -	 Color Mode	 Auto / Mode
 Mute	 Mute / Focus	 Fast/Fine	 -- / USB
 Menu	 Menu / Info	 3D Format	 7 / S-Vid
 Esc	 Exit / Lamp	 RGBCMY	 4 / VGA1
 Default	 Pict / Freeze	 Auto Iris	 Hide / Blank
 Up	 Up	 Slideshow	 SRC / Search
 Down	 Down	 Pattern	 1 / Point
 Enter	 OK	 2D/3D	 5 / VGA2
 Right	 Right	 User	 6 / Comp
 Left	 Left	 Aspect	 Aspect / Re-Sync
 LAN	 0 / Lan	 A/V Mute	 Shift + Mute / Focus
 Video	 8 / Video	 <<	 Shift + 1 / Point
 PC	 K.S. / PIP	 Play	 Shift + 2
 HDMI 1	 2	 >>	 Shift + 3
 HDMI 2	 3	 I<<	 Shift + 4 / VGA1





Original	Recharge	Original	Recharge
 Pause	 +  Shift + 5 / VGA2		
 >>	 +  Shift + 6 / Comp		
 Stop	 +  Shift + 8 / Video		

Original	Recharge

