



Original	Rechange
 Power	 Power
 Call	 Pre Ch
 Mute	 Mute
 Source	 AV
 P.Mode	 Shift + Format
 S.Mode	 Shift + Dual
 I / II	 Dual
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Original	Rechange
 0	 0
 -/--/---	 Guide
 QV	 Smart
 TV Menu	 Menu
 TV / Text	 Text
 Mix	 Media
 Call	 Back
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 V +	 Vol +
 V -	 Vol -
 P +	 Ch +
 P -	 Ch -
 Red	 Red





Original	Recharge	Original	Recharge
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Subtitle		Subt
	Hold		Pause
	Size		Format
	Reveal		TV/R
	Index		Info
	Cancel		Exit

