






















































	Original	Recharge		Original	Recharge
	Power		Power		[i+]/[?]
	Source		AV		Return
	[+]		3D		Zoom
	I<<		I<<		Menu
	>>I		>>I		Up
	<<		<<		Down
	>>		>>		Right
	Stop		Stop		Left
	Play		Play		OK
	Pause		Pause		1
	Red		Red		2
	Green		Green		3
	Yellow		Yellow		4
	Blue		Blue		5
	Repeat		Shift + Text		6
	Audio		Dual		7
	Guide		Guide		8



