














Original	Rechange
 Mute	 Mute
 Power	 Power
 Subtitle	 Subt
 Language	 Dual
 Open / Close	 Eject
 Angle	 Format
 Prog	 Sleep
 Title	 List
 Menu	 Menu
 Vol +	 Vol +
 Vol -	 Vol -
 Setup	 Options
 Play / Pause	 Play
 Play / Pause	 Pause
 Up	 Up
 Down	 Down
 Right	 Right

Original	Rechange
 Left	 Left
 Enter	 Ok
 Stop	 Stop
 L / R	 3D
 1	 1
 2	 2
 Goto	 Media
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 10+	 Guide
 0	 0
 << Rev	 <<





Original	Recharge	Original	Recharge
 >> Fwd	 >>		
 I<< Prev	 I<<		
 >>I Next	 >>I		
 Display	 Info		
 Slow	 +  Shift + Play		
 Step	 +  Shift + Pause		
 PBC	 Smart		
 Zoom	 +  Shift + Eject		
 Repeat	 Text		
 A - B	 +  Shift + Text		
 Video / Mode	 TV/R		

Original	Recharge

