

































































	Original	Recharge
	Power	 Power
	Clock Timer	 3D
	Clock Timer Set	 Options
	1	 1
	2	 2
	3	 3
	4	 4
	5	 5
	6	 6
	7	 7
	8	 8
	9	 9
	0/10	 0
	>10	 Guide
	Clear	 Exit
	Vol+	 Vol +
	Vol-	 Vol -

	Original	Recharge
	Sleep	 Sleep
	Enter	 Ok
	Tuner Memory	 TV/R
	Display	 Info
	Play	 Play
	Pause	 Pause
	Stop	 Stop
	>>I/Preset+	 >>I
	I<</Preset-	 I<<
	>>/Tuning+	 >>
	<</Tuning-	 <<
	Album+	 Ch +
	Album-	 Ch -
	Bass/Treble	 Dual
	DSG	 Smart
	Function	 Menu

