






















































	Original	Rechange		Original	Rechange
	Stop/Eject		Stop		Frm/Tim
	1		1		Chap
	2		2		Chp/Tim
	3		3		Search
	4		4		Esc
	5		5		Disp
	6		6		Dig/Ana
	7		7		Cx
	8		8		Test
	9		9		Side A
	0		0		Side B
	+10		Guide		I<< Chapter Skip
	Speed+		Ch +		>>I Chapter Skip
	Speed-		Ch -		<II Still Step
	Tv/Dvd		TV/R		II>Still Step
	Clear		Shift + Exit		<<Scan
	Stereo		Dual		>>Scan



