







Original	Recharge
 Power Tv	 Power
 Mute	 Mute
 I=Q	 Dual
 [><]	 3D
 Timer	 Shift + AV
 Input/[+]	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 [i+]/[?]	 Info

Original	Recharge
 Recall	 Pre Ch
 Red/♪	 Red
 Green/*	 Green
 Yellow	 Yellow
 Blue/[+]	 Blue
 []	 Format
 [≡]	 Text
 Menu	 Menu
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Pause	 Pause
 Stop	 Stop
 >>	 >>
 <<	 <<





Original	Recharge
Rec	Rec
Play	Play
[]	Guide
Vol+	Vol +
Vol-	Vol -
PR+	Ch +
PR-	Ch -
Power VCR	Shift + Power
1 VCR	Shift + 1
2 VCR	Shift + 2
3 VCR	Shift + 3
4 VCR	Shift + 4
5 VCR	Shift + 5
6 VCR	Shift + 6
7 VCR	Shift + 7
8 VCR	Shift + 8
9 VCR	Shift + 9

Original	Recharge
0 VCR	Shift + 0
Recall VCR	Shift + Pre Ch
PR+ VCR	Shift + Ch +
PR- VCR	Shift + Ch -

