

































































| Original | Recharge |
|--|---|
|  Power |  Power |
|  Red |  Red / Netflix / Search |
|  Green |  Green / APP / Repeat |
|  Yellow |  Yellow / YouTube / Repeat |
|  Blue |  Blue / Prime Video / Random |
|  TV/SAT |  AV / Input / RDS |
|  TV/Radio |  TV/Radio / |
|  Zoom |  Zoom / Size |
|  List |  Smart / List |
|  Audio |  Audio / Lang I/II |
|  EPG |  Guide / EPG / -/-- |
|  Timer |  Sleep / Timer |
|  Text |  Text / Goto |
|  Exit |  Exit / Cancel / Clear |
|  Menu |  Menu / Home |
|  M/P |  Display / Media |
|  Mute |  Mute / Dimmer |

| Original | Recharge |
|--|---|
|  CH+ |  CH+ / Page+ |
|  CH- |  CH- / Page- |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  OK |  OK |
|  Vol+ |  Vol+ |
|  Vol- |  Vol- |
|  Recall |  Back / Return |
|  P+ |  >> / Preset+ |
|  P- |  << / Preset- |
|  FAV |  Fav / Marker / PC |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |





| Original | | Rechange | | Original | | Rechange | |
|----------|-------|---------------------|-----------------------|----------|--|----------|--|
| 5 | 5 | TAPE 5 | 5 | | | | |
| 6 | 6 | TUNER 6 | 6 | | | | |
| 7 | 7 | AUX - HDD 7 | 7 | | | | |
| 8 | 8 | USB 8 | 8 | | | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | | | |
| 0 | 0 | HDMI - BAT 0 | 0 | | | | |
| INFO | Info | ANGLE INFO | Info / Angle | | | | |
| PAUSE | Pause | STEP - FREEZE II | Pause / Step / Freeze | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |





| Original | Rechange |
|----------|-------------------|
| Power | Power |
| SAT | Smart / List |
| Info | Info / Angle |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 0 / Zoom | Zoom / Size |
| 0 / Zoom | 0 |
| Audio | Audio / Lang I/II |
| Mute | Mute / Dimmer |
| Recall | Back / Return |

| Original | Rechange |
|--------------|-----------------------------|
| FAV | Fav / Marker / PC |
| Up / CH+ | CH+ / Page+ |
| Down / CH- | Down |
| Up / CH+ | Up |
| Right / Vol+ | Right |
| Right / Vol+ | Vol+ |
| Down / CH- | CH- / Page- |
| Left / Vol- | Vol- |
| Left / Vol- | Left |
| OK | OK |
| Menu | Menu / Home |
| Exit | Exit / Cancel / Clear |
| Blue / Pause | Blue / Prime Video / Random |
| Blue / Pause | Pause / Step / Freeze |
| Red / Text | Red / Netflix / Search |
| Red / Text | Text / Goto |
| Multivideo | Display / Media |





































| Original | Recharge | Original | Recharge |
|---|---|----------|----------|
|  Yellow / Subtitle |  Yellow / YouTube / Repeat | | |
|  Yellow / Subtitle |  Subtitle / EQ | | |
|  TV / AV |  AV / Input / RDS | | |
|  Green / P/N |  Green / APP / Repeat | | |
|  TV / Radio |  TV/Radio / | | |
|  SAT |  Shift + 0 | | |
|  EPG |  Guide / EPG / -/-- | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Recharge |
|----------|----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |














| Original | Rechange | |
|------------|---|-----------------------|
| Mute |  | Mute / Dimmer |
| PWR On/Off |  | Power |
| App |  +  | Shift + Green / APP / |
| Epg |  | Guide / EPG / -/-- |
| Info |  | Info / Angle |
| Subt.List |  | Subtitle / EQ |
| TV |  | TV/Radio / |
| Text |  | Text / Goto |
| Zoom |  | Zoom / Size |
| Menu |  | Menu / Home |
| TV/SAT |  | AV / Input / RDS |
| Menu Up |  | Up |
| Display |  | Display / Media |
| Menu Left |  | Left |
| OK Enter |  | OK |
| Menu Right |  | Right |
| Exit |  | Exit / Cancel / Clear |

| Original | Rechange | |
|--------------|---|----------------------------|
| Menu Down |  | Down |
| Back |  | Back / Return |
| Volume+ |  | Vol+ |
| CH/Page+ |  | CH+ / Page+ |
| Volume- |  | Vol- |
| CH/Page- |  | CH- / Page- |
| Audio |  | Audio / Lang I/II |
| 1. ? |  | 1 |
| 2abc |  | 2 |
| 3def |  | 3 |
| 4ghi |  | 4 |
| 5jkl |  | 5 |
| 6mno |  | 6 |
| 7pqrm |  | 7 |
| 8tuv |  | 8 |
| 9wxyz |  | 9 |
| Guide Pilote |  +  | Shift + Guide / EPG / -/-- |




























| Original | Recharge | Original | Recharge |
|-----------|---|----------|----------|
| 0/10 |  0 | | |
| FAV Pref. |  Fav / Marker / PC | | |
| Red |  Red / Netflix / Search | | |
| Green |  Green / APP / Repeat | | |
| Yellow |  Yellow / YouTube / Repeat | | |
| Blue |  Blue / Prime Video / Random | | |
| Dec/Pause |  Pause / Step / Freeze | | |
| |  Smart / List | | |
| |  D.Menu / Top | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Recharge |
|----------|----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |











| Original | Recharge | Original | Recharge |
|----------|---|-----------------------|-----------------------|
| Power |  | Power | Power |
| Mute |  | Mute / Dimmer | Mute / Dimmer |
| Pause |  | Pause / Step / Freeze | Pause / Step / Freeze |
| Audio |  | Audio / Lang I/II | Audio / Lang I/II |
| Zoom |  | Zoom / Size | Zoom / Size |
| Timer |  | Sleep / Timer | Sleep / Timer |
| Tv/Radio |  | TV/Radio / | TV/Radio / |
| Text |  | Text / Goto | Text / Goto |
| Tv/SAT |  | AV / Input / RDS | AV / Input / RDS |
| Menu |  | Menu / Home | Menu / Home |
| Up/CH+ |  | Up | Up |
| Info |  | Info / Angle | Info / Angle |
| Left |  | Left | Left |
| OK |  | OK | OK |
| Right |  | Right | Right |
| Exit |  | Exit / Cancel / Clear | Exit / Cancel / Clear |
| Down/CH- |  | Down | Down |

| Original | Recharge | Original | Recharge |
|----------|---|-------------------|-------------------|
| Recall |  | Back / Return | Back / Return |
| Vol+ |  | Vol+ | Vol+ |
| List |  | Smart / List | Smart / List |
| P+ |  | CH+ / Page+ | CH+ / Page+ |
| Vol- |  | Vol- | Vol- |
| M/P |  | Display / Media | Display / Media |
| P- |  | CH- / Page- | CH- / Page- |
| 1 |  | 1 | 1 |
| 2 |  | 2 | 2 |
| 3 |  | 3 | 3 |
| 4 |  | 4 | 4 |
| 5 |  | 5 | 5 |
| 6 |  | 6 | 6 |
| 7 |  | 7 | 7 |
| 8 |  | 8 | 8 |
| 9 |  | 9 | 9 |
| EPG |  | Guide / EPG / -/- | Guide / EPG / -/- |





| Original | Recharge | |
|--------------|---|-----------------------------|
| 0/Sleeptimer |  | 0 |
| FAV |  | Fav / Marker / PC |
| Red |  | Red / Netflix / Search |
| Green |  | Green / APP / Repeat |
| Yellow |  | Yellow / YouTube / Repeat |
| Blue |  | Blue / Prime Video / Random |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

| Original | Recharge |
|----------|----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

