






	Original	Rechange		Original	Rechange
	Power		Power		FAV
	Mute		Mute		Page+
	1		1		Page-
	2		2		Up/CH+
	3		3		Down/CH-
	4		4		Right
	5		5		Left
	6		6		OK
	7		7		Vol+
	8		8		Vol-
	9		9		Red
	0		0		Green
	Info		Info		Yellow
	Recall		Back		Blue
	Menu		Menu		Audio
	EPG		Guide		Pause
	Exit		Exit		TTX
					Pre Ch
					Ch +
					Ch -
					Up
					Down
					Right
					Left
					Ok
					Vol +
					Vol -
					Red
					Green
					Yellow
					Blue
					Dual
					Pause
					Text





Original		Rechange		Original		Rechange	
	Subtitle		Subt				
	Tv/Radio		TV/R				

