



| Original | Rechange           |
|----------|--------------------|
| P100     | Guide / EPG / -/-- |
| Power    | Power              |
| REV      | Sleep / Timer      |
| DOUB     | Smart / List       |
| 1        | 1                  |
| 2        | 2                  |
| 3        | 3                  |
| Hold     | Stop / Hold        |
| 4        | 4                  |
| 5        | 5                  |
| 6        | 6                  |
| SUB      | Subtitle / EQ      |
| Update   | Display / Media    |
| 7        | 7                  |
| 8        | 8                  |
| 9        | 9                  |
| MIX      | D.Menu / Top       |

| Original | Rechange         |
|----------|------------------|
| AV       | AV / Input / RDS |
| 0        | 0                |
| TV       | TV/Radio /       |
| P+       | Up               |
| P+       | CH+ / Page+      |
| Mute     | Mute / Dimmer    |
| TV/TXT   | Text / Goto      |
| Menu     | Menu / Home      |
| Vol-     | Vol-             |
| Vol-     | Left             |
| OK       | OK               |
| Vol+     | Vol+             |
| Vol+     | Right            |
| SWAP     | Back / Return    |
| P-       | CH- / Page-      |
| P-       | Down             |
| 16:9     | Picture / Format |





|   | Original    | Recharge  |  | Original | Recharge |
|---|-------------|---|--|----------|----------|
|  | Red         |  Red / Netflix / Search      |  |          |          |
|  | Green       |  Green / APP / Repeat        |  |          |          |
|  | Yellow      |  Yellow / YouTube / Repeat   |  |          |          |
|  | Blue        |  Blue / Prime Video / Random |  |          |          |
|  | Violet/Info |  Info / Angle                |  |          |          |
|  | [ ]         |  Zoom / Size                 |  |          |          |
|  | PC          |  Fav / Marker / PC           |  |          |          |
|  | PT          |  Setup / OPT /               |  |          |          |
|   |             |   |  |          |          |
|   |             |   |  |          |          |
|   |             |   |  |          |          |
|   |             |   |  |          |          |
|   |             |   |  |          |          |
|   |             |   |  |          |          |
|   |             |   |  |          |          |
|   |             |   |  |          |          |
|   |             |   |  |          |          |

|  | Original | Recharge |
|--|----------|----------|
|  |          |          |
|  |          |          |
|  |          |          |
|  |          |          |
|  |          |          |
|  |          |          |
|  |          |          |
|  |          |          |
|  |          |          |
|  |          |          |
|  |          |          |
|  |          |          |
|  |          |          |
|  |          |          |
|  |          |          |
|  |          |          |
|  |          |          |
|  |          |          |
|  |          |          |

