



Original	Rechange
Power	Power
Source	AV
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
www. Browser	Media
Refresh	Guide
Home	Smart
TXT / Mix	Text
Stop	Stop
Subtitle	Subt
Audio	Dual
Screenshot	Shift + Media
<< / Index	Shift + Info
<< / Index	<<
>> / Hold	Shift + Stop

Original	Rechange
>> / Hold	>>
<<< / Reveal	3D
<<< / Reveal	<<<
>> / Cancel	Shift + Exit
>> / Cancel	>>
Subpage	Shift + Subt
Aspect	Format
Freeze	Shift + Pause
FAV	Pre Ch
Menu	Menu
Exit	Exit
Up	Up
Right	Right
Down	Down
Left	Left
Enter	Ok
Play/Pause / Size	Eject



