







































































Original	Recharge	Original	Recharge
 Power	 Power	 Skip >>I	 >>I
 Select Drive	 Eject	 I<< Skip	 I<<
 1	 1	 << Slow Search	 <<
 2	 2	 Slow/Search >>	 >>
 3	 3	 Stop	 Stop
 4	 4	 Pause/Pause Live	 Pause
 5	 5	 Play	 Play
 6	 6	 i/Status	 Info
 7	 7	 X/Exit	 Exit
 8	 8	 Option	 Options
 9	 9	 Back/Return	 Back
 0	 0	 Direct Navigator	 List
 Last View	 Pre Ch	 Guide	 Guide
 Radio/TV	 TV/R	 Function Menu	 Menu
 CH/Page+	 Ch +	 Up	 Up
 CH/Page-	 Ch -	 Down	 Down
 Internet	 Smart	 Right/I>	 Right





Original	Recharge
< /Left	Left
OK	Ok
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
Rec	Rec
AD	+  Shift + Subt
Text	Text
STTL	Subt
Prog/Check	Sleep
Chapter	Format
Del	Dual
Time Slip	3D
Netflix	Media
Setup	D. Menu
Manual Skip -10s	+  Shift +  <<

Original	Recharge
Manual Skip +60s	+  Shift + >>
Power Tv	+  Shift + Power
AV Input Tv	AV
Vol+ Tv	Vol +
Vol- Tv	Vol -
CH+ Tv	+  Shift + Ch +
CH- Tv	+  Shift + Ch -

