







































































Original	Rechange	Original	Rechange
 Power	 Power	 0	 0
 FAV / Eject	 Pre Ch	 Recall	 Back
 FAV / Eject	 Eject	 -/--	 Shift + Guide
 Mute	 Mute	 Red / Goto	 Red
 P.Mode	 Format	 Green / A-B	 Green
 S.Mode	 Dual	 Yellow / Repeat	 Yellow
 Sleep	 Sleep	 Blue / Angle	 Blue
 Scaler	 Smart	 Setup	 Menu
 1	 1	 Exit	 Exit
 2	 2	 Up	 Up
 3	 3	 Left	 Left
 4	 4	 OK	 Ok
 5	 5	 Right	 Right
 6	 6	 Down	 Down
 7	 7	 CH +	 Ch +
 8	 8	 CH -	 Ch -
 9	 9	 Vol +	 Vol +





Original		Rechange		Original		Rechange	
	Vol -		Vol -		Radio / Zoom -		TV/R
	Text / Play		Text		Radio / Zoom -	+	Shift + Down
	Text / Play		Play		EPG / Zoom +		Guide
	Mix / Pause	+	Shift + Text		EPG / Zoom +	+	Shift + Up
	Mix / Pause		Pause		S.Title / Subtitle		Subt
	Index / Stop	+	Shift + Info				
	Index / Stop		Stop				
	Source		AV				
	Cancel / <<		<<				
	Reveal / >>		>>				
	Hold / I<<		I<<				
	Size / >>I		>>I				
	S.Page /		D. Menu				
	Page - / Title	+	Shift + Ch -				
	Page + / PBC	+	Shift + Ch +				
	I/II / Audio	+	Shift + Dual				
	i / Display		Info				

