



	Original	Rechange
	Power	Power
	Setup	Options
	Mute	Mute
	Function	Menu
	1	1
	2	2
	3	3
	4	4
	5	5
	6	6
	7	7
	8	8
	9	9
	0	0
	Audio	Dual
	Subtitle	Subt
	Digest	Smart

	Original	Rechange
	EPG	Guide
	Info	Info
	FAV	Pre Ch
	Red/Photo	Red
	Green/Music	Green
	Yellow/Movie	Yellow
	Blue/Calendar	Blue
	Zoom	Eject
	Teletext	Text
	Tv/Radio	TV/R
	Recall	Back
	Exit	Exit
	Up	Up
	Down	Down
	Right	Right
	Left	Left
	Play/Pause	Ok



