








































Original	Rechange
 Power	 Power
 D/A Tv	 Smart
 Input	 AV
 Guide	 Guide
 Radio	 TV/R
 Subtitle*	 Subt
 PIP PR-	 Shift + Ch +
 PIP PR+	 Shift + Ch -
 Swap	 Media
 PIP Input	 Shift + AV
 PIP	 Shift + 3D
 Info	 Info
 Back	 Back
 ARC	 3D
 Menu	 Menu
 Text	 Text
 Exit	 Exit

Original	Rechange
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 FAV	 Pre Ch
 CH+	 Ch +
 CH-	 Ch -
 1	 1
 2	 2





Original		Rechange	
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	List		List
	Q.View		D. Menu
	[≡♦]/Size		Format
	[≡X]/Position		Eject
	[≡i]/Scan/Index	+	Shift + Info
	[≡o]/Time	+	Shift + Text
	[≡?]/Reveal		Options
	[≡+]/Hold	+	Shift + Subt
	I/II		Dual

Original		Rechange	
	Sleep		Sleep










































Original	Rechange	Original	Rechange
Power	Power	Play	Play
Menu	Menu	Pause	Pause
Up	Up	Stop	Stop
OK	Ok	<<	<<
Down	Down	>>	>>
Right	Right	I<<	I<<
Left	Left	>>I	>>I
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
0	0		





	Original	Recharge		Original	Recharge
	Power		Power		Rec
	Input		AV		<<
	CH+		Ch +		>>
	CH-		Ch -		
	1		1		
	2		2		
	3		3		
	4		4		
	5		5		
	6		6		
	7		7		
	8		8		
	9		9		
	0		0		
	Play		Play		
	Pause		Pause		
	Stop		Stop		

