








































| Original | Recharge |
|--|---|
|  Power |  Power |
|  Goto |  Smart |
|  Open/Close |  Eject |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  10+ |  Guide |
|  Zoom+ |  Ch + |
|  Zoom- |  Ch - |
|  Vol+ |  Vol + |

| Original | Recharge |
|--|---|
|  Vol- |  Vol - |
|  Mute |  Mute |
|  <</REV |  << |
|  >>/FWD |  >> |
|  <</Prev |  << |
|  >> /Next |  >> |
|  Play |  Play |
|  Pause |  Pause |
|  Stop |  Stop |
|  Step |  Pre Ch |
|  Menu |  Menu |
|  Title |  Info |
|  Setup |  Options |
|  PBC |  Yellow |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |





| Original | | Recharge | |
|---|----------|---|--------|
|  | Left |  | Left |
|  | OK |  | Ok |
|  | OSD |  | List |
|  | Angle |  | AV |
|  | Subtitle |  | Subt |
|  | Video |  | TV/R |
|  | A-B |  | Media |
|  | Prog |  | Sleep |
|  | Return |  | Back |
|  | Repeat |  | Text |
|  | Slow |  | Format |
|  | Audio |  | Dual |
|  | N/P |  | 3D |
|  | Clear |  | Exit |
| | | | |
| | | | |
| | | | |

| Original | | Recharge | |
|----------|--|----------|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

