



	Original	Rechange	Original	Rechange
	Power	 Power		
	Recharging	 Aspect Eco / Aspect		
	Auto	 Auto		
	Spot	 Source		
	Max	 Mode		
	Up	 Up		
	Right	 Right		
	Left	 Left		
	Start/Stop	 Enter		
	Manual	 Video Comp / Video		
	Edge	 Page▲ Vol + / Page +		
	Clock	 Menu		
	Timer/Daily	 Timer Freeze / Timer		
	No Name Left	 Play + / Play		
	No Name Right	 Focus Volt / Focus		

