







































































| Original | Rechange | Original | Rechange |
|--|---|---|---|
|  Standby / On |  Power |  Vol + |  Vol + |
|  Function |  AV |  Vol - |  Vol - |
|  Open / Close |  Eject |  Mute |  Mute |
|  Karaoke |  TV/R |  Top Menu |  Shift + Menu |
|  Key / Echo |  Guide |  Menu / PopUp |  Menu |
|  NET Contents |  Media |  Home Menu |  Smart |
|  YouTube |  Shift + Media |  Up |  Up |
|  Sleep |  Sleep |  Left |  Left |
|  Exit |  Exit |  Return |  Back |
|  Mic Vol + |  Ch + |  Enter |  Ok |
|  Mic Vol - |  Ch - |  Right |  Right |
|  Home Media |  Shift + Smart |  Down |  Down |
|  Dimmer |  Shift + Mute |  Resolution |  Format |
|  CD / SACD |  D. Menu |  Replay |  Shift + Play |
|  Display |  Info |  Continued |  List |
|  USB REC |  Rec |  Tools |  Options |
|  Sound |  Shift + Dual |  Skip Search |  Shift + Right |





| Original | Rechange |
|----------------|----------|
| << REV | << |
| Play | Play |
| >> FWD | >> |
| I<< / < / < | I<< |
| Pause | |
| Stop | ■ |
| >> / > / > | >> |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 0 | 0 |

| Original | Rechange |
|------------------------|----------------|
| Clear | Shift + Exit |
| Repeat | Text |
| Subtitle | Subt |
| Angle | Shift + Format |
| Virtual 3D Sound | 3D |
| A-B | Shift + Text |
| Program / Red | Red |
| Program / Red | Shift + Sleep |
| RDS / Bookmark / Green | Green |
| Audio | Dual |
| RDS / Bookmark / Green | Pre Ch |
| PTY / Zoom / | Yellow |
| PTY / Zoom / | Shift + Eject |
| Index / Blue | Blue |
| | |
| | |
| | |

