



Original	Recharge
Power On/Off	Power
Display	Info
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
CH Enter	Pre Ch
P/CH+	Ch +
P/CH-	Ch -
Muting	Mute

Original	Recharge
I-II MTS	Dual
Vol+	Vol +
Vol-	Vol -
Integrator	Smart
Home	Menu
Exit	Exit
Return	Back
Up	Up
Down	Down
Right	Right
Left	Left
Enter/Set	Ok
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
PC	Media





Original	Recharge
INPUT	TIMER AV
EXT INPUT	SHIFT + TIMER AV
TV	SEARCH TV/R
SPLIT	SHIFT + ECO 3D
SUB INPUT	AD SUBT
SWAP	PROG SLEEP
(PIP) SHIFT	ECO 3D
DRIVE OFF	SHIFT + SETTINGS OPT
FACTORY	E-MANUAL D.MENU
2nd FACTORY	REPEAT TEXT
AUTO SET UP	SETTINGS OPT
ID NO. SET -	SHIFT + SEARCH TV/R
CLEAR +	SHIFT + CLEAR EXIT
POWER CONTROL	SHIFT + POWER
AV SELECTION	DISC NAV LIST
POWER OFF	SHIFT + APP MEDIA
POWER ON	SHIFT + HOME SMART

Original	Recharge
POINT ZOOM	ZOOM Eject
ZOOM -	SHIFT + CH -
ZOOM +	SHIFT + CH +
FREEZE	Pause
SCREEN SIZE	PICTURE FORMAT
1	SHIFT + 1
2	SHIFT + 2
3	SHIFT + 3
4	SHIFT + 4
5	SHIFT + 5
6	SHIFT + 6
7	SHIFT + 7
8	SHIFT + 8





Original	Recharge
Power On/Off	Power
Display	Info
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
CH Enter	Pre Ch
.	Guide
P/CH+	Ch +
P/CH-	Ch -
Muting	Mute

Original	Recharge
I-II MTS	Dual
Vol+	Vol +
Vol-	Vol -
Integrator	Smart
Home	Menu
Exit	Exit
Return	Back
Up	Up
Down	Down
Right	Right
Left	Left
Enter/Set	Ok
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
PC	Media





Original	Recharge
INPUT	AV
EXT INPUT	SHIFT + AV
TV	TV/R
SPLIT	SHIFT + 3D
SUB INPUT	SUBT
SWAP	SLEEP
(PIP) SHIFT	3D
DRIVE OFF	SHIFT + OPT
FACTORY	D. Menu
2nd FACTORY	Text
AUTO SET UP	Options
ID NO. SET -	SHIFT + TV/R
CLEAR +	SHIFT + EXIT
POWER CONTROL	SHIFT + Power
AV SELECTION	List
POWER OFF	SHIFT + MEDIA
POWER ON	SHIFT + Smart

Original	Recharge
Zoom-	SHIFT + CH -
Zoom/Point	Eject
Zoom+	SHIFT + CH +
Freeze	Pause
Size/Screen	Format
Input 1	SHIFT + 1
Input 2	SHIFT + 2
Input 3	SHIFT + 3
Input 4	SHIFT + 4
Input 5	SHIFT + 5
Input 6	SHIFT + 6
Input 7	SHIFT + 7
Input 8	SHIFT + 8

