







































































Original		Recharge		Original		Recharge	
	Power		Power		List		List
	Sleep		Sleep		Back		Back
	Mute		Mute		Menu		Menu
	Mode		Smart		CH +		Ch +
	1		1		CH -		Ch -
	2		2		Vol +		Vol +
	3		3		Vol -		Vol -
	4		4		Up		Up
	5		5		Left		Left
	6		6		OK		Ok
	7		7		Right		Right
	8		8		Down		Down
	9		9		FAV		Pre Ch
	0		0		EPG		Guide
	Nicam/A2		Dual		Info		Info
	TXT / Mix		Text		Exit		Exit
	TV / Radio		TV/R		Red		Red



