



Original		Rechange		Original		Rechange	
	Power		Power				
	AUX		Red				
	TAPE 1/2		Green				
	CD		Yellow				
	TUNER		Blue				
	INC SURR.		Smart				
	DBB		Guide				
	DSC		Pre Ch				
	Vol+		Vol +				
	Vol-		Vol -				
	Mute		Mute				
> button icon"/>	>	>> button icon"/>	>>				
	<		<<				
>> button icon"/>	>>		>>				
<< button icon"/>	<<	<< button icon"/>	<<				
	Program		Sleep				





Original	Recharge	Original	Recharge
Power	Power	I<	I<<
AUX	Red	Stop	Stop
Tape 1/2	Green	>>	>>>
CD	Yellow	<<	<<<
Tuner	Blue	Repeat	Text
INC SURR.	Smart	Shuffle	Media
1 CD Direct	1	Program	Sleep
2 CD Direct	2		
3 CD Direct	3		
DBB	Guide		
DSC	Pre Ch		
Vol+	Vol +		
Vol-	Vol -		
Mute	Mute		
Pause	Pause		
Play	Play		
>I	>>I		

Original	Recharge	Original	Recharge
Power	Power	I<	I<<
AUX	Red	Stop	Stop
Tape 1/2	Green	>>	>>>
CD	Yellow	<<	<<<
Tuner	Blue	Repeat	Text
INC SURR.	Smart	Shuffle	Media
1 CD Direct	1	Program	Sleep
2 CD Direct	2		
3 CD Direct	3		
DBB	Guide		
DSC	Pre Ch		
Vol+	Vol +		
Vol-	Vol -		
Mute	Mute		
Pause	Pause		
Play	Play		
>I	>>I		



























Original		Recharge		Original		Recharge	
	Power		Power		>>		>>
	AUX		Red				
	TAPE 1/2		Green				
	CD		Yellow				
	Tuner		Blue				
	INC SURR.		Smart				
	DBB		Guide				
	DSC		Pre Ch				
	Vol+		Vol +				
	Vol-		Vol -				
	Mute		Mute				
	Pause		Pause				
	Play		Play				
	>		>>				
	<		<<				
	Stop		Stop				
	>>		>>				





Original	Recharge	Original	Recharge
 Power	 Power		
 AUX	 Red		
 TAPE 1/2	 Green		
 CD	 Yellow		
 Tuner	 Blue		
 INC SURR.	 Smart		
 DBB	 Guide		
 DSC	 Pre Ch		
 Vol+	 Vol +		
 Vol-	 Vol -		
 Mute	 Mute		

