







































































Original	Rechange	Original	Rechange
 POWER	 Power	 TEXT	 Text
 SOURCE	 AV	 0	 0
 ASPECT	 Format	 RECALL	 Back
 MENU	 Menu	 TV	 TV/R
 S.MODE	 Shift + Dual	 ^	 Up
 P.MODE	 Shift + Format	 >	 Right
 1	 1	 v	 Down
 2	 2	 <	 Left
 3	 3	 MENU	 Ok
 MUTE	 Mute	 VOL+	 Vol +
 4	 4	 VOL-	 Vol -
 5	 5	 CH-	 Ch -
 6	 6	 CH+	 Ch +
 DISPLAY	 Info	 SLEEP	 Sleep
 7	 7	 SUBCODE	 Subt
 8	 8	 ZOOM	 Eject
 9	 9	 STILL	 Pause



