
























































































Original	Rechange	Original	Rechange
 Power	 Power	 Vol-	 Vol -
 Open/Close	 Eject	 I<<	 I<<
 Function	 Guide	 I>>	 I>>
 [I]/PLII/S.Vol	 Dual	 <<	 <<
 Mute	 Mute	 >>	 >>
 DSP/EQ	 TV/R	 Stop	 Stop
 1	 1	 Play	 Play
 2	 2	 Pause	 Pause
 3	 3	 Disc Menu	 D. Menu
 4	 4	 Home	 Smart
 5	 5	 Title Menu	 Menu
 6	 6	 Tools	 Options
 7	 7	 Info	 Info
 8	 8	 Return	 Back
 9	 9	 Exit	 Exit
 0	 0	 Up/Tuning Up	 Up
Vol+	Vol +	Down/Tuning	Down



Down



	Original	Rechange	Original	Rechange
	Right			
	Left			
	Enter			
	Red/Audio Upscale/P.Bass			
	Green/S/W/Leve			
	Yellow/Giga			
	Blue/MO/ST			
	USB Rec			
	Dimmer			
	Repeat			
	Tuner Memory	