







































































Original		Rechange		Original		Rechange	
	Power		Power		9		9
	<<		<<		0		0
	>>		>>		i		Info
	Stop		Stop		Rec		Rec
	Play/Pause		Play		Vol+		Vol +
	Red		Red		Vol-		Vol -
	Green		Green		CH+		Ch +
	Yellow		Yellow		CH-		Ch -
	Blue		Blue		Guide		Guide
	1		1		Mute		Mute
	2		2		FAV		Pre Ch
	3		3		Text		Text
	4		4		Menu		Menu
	5		5		Exit		Exit
	6		6		Up		Up
	7		7		Down		Down
	8		8		Right		Right





Original		Rechange		Original		Rechange	
	Left		Left				
	OK		Ok				
	Back		Back				
	Lang(AD)		Dual				
	Subtitle		Subt				
	Tv/Radio		TV/R				

