







































































Original		Rechange		Original		Rechange	
	Power		Power		0		0
	Display		Info		Recall		Pre Ch
	Mute		Mute		Enter		Guide
	TV		TV/R		Menu		Menu
	AV		AV		TTX/MIX		Text
	Scart		Smart		Wide		3D
	PC		Media		MPX		Options
	Sleep		Sleep		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Vol+		Vol +
	6		6		Vol-		Vol -
	7		7		CH+		Ch +
	8		8		CH-		Ch -
	9		9		Red		Red





Original	Rechange	Original	Rechange
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Subtitle	 Subt		
 Index	 List		
 Subpage	 D. Menu		
 Reveal	 Dual		
 Size	 Format		
 Hold	 Eject		

