





































| Original | Recharge | Original | Recharge |
|--------------|---|------------|---|
| On/Off |  Power | Menu Left |  Left |
| Audio Off |  Mute | OK Enter |  Ok |
| Slow Down |  Ch - | Next |  >> |
| Slow Up |  Ch + | Progr. |  Sleep |
| Stop |  Stop | Menu Right |  Right |
| Pause |  Pause | Prev. |  << |
| Subt. |  Subt | Menu Down |  Down |
| Auto/Track |  3D | Volume+ |  Vol + |
| Title |  List | Volume- |  Vol - |
| Rep/A-B |  +  Shift + Text | Top Menu |  D. Menu |
| Pepeat/1/All |  Text | 1 |  1 |
| Zoom |  +  Shift + Eject | 2 |  2 |
| DVD/TV |  Smart | 3 |  3 |
| Menu |  Menu | 4 |  4 |
| Menu Up |  Up | Rewind |  << |
| Display |  Info | Play |  Play |
| Return |  Back | F.Forward |  >> |



| Original | Recharge | Original | Recharge |
|------------|--|----------|----------|
| Digest |  +  Shift + Info | | |
| Angle |  Format | | |
| 5 |  5 | | |
| 6 |  6 | | |
| 7 |  7 | | |
| 8 |  8 | | |
| Pbc |  Green | | |
| Audio |  Dual | | |
| Record |  Rec | | |
| Video |  Media | | |
| 9 |  9 | | |
| Np |  Red | | |
| Setup |  Options | | |
| +10 |  Guide | | |
| 0 |  0 | | |
| Open/Close |  Eject | | |
| C/CH |  Pre Ch | | |

