






















































	Original	Recharge		Original	Recharge
	Power		Power		Rec
	Home		Smart		Rec
	1		1		Stop
	2		2		Pause
	3		3		Play
	4		4		Vol+
	5		5		Vol-
	6		6		Setup
	7		7		I<< Prev
	8		8		>>I Next
	9		9		<< FR
	0		0		>> FF
	Goto		List		Up
	Mute		Mute		Left
	Display		Info		Enter
	Audio		Dual		Right
	Subtitle		Subt		Down
					Browser
					Media





Original		Rechange		Original		Rechange	
	Return		Back				
	Red / Slow		Red				
	Green / TimeShift		Green				
	Yellow / CM Skip		Yellow				
	Blue / Replay		Blue				
	Repeat		Text				
	Zoom		Eject				
	Copy		3D				
	TV System		TV/R				
	Source		AV				
	EPG		Guide				
	Edit		Format				
	Timer		Shift + AV				

