




























































Original	Rechange
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 A-Z	 AV
 Tv/Radio	 TV/R
 Mute	 Mute
 UHF	 Smart
 Pause	 Pause
 EPG	 Guide

Original	Rechange
 ♥/FAV	 Pre Ch
 Menu	 Menu
 Back	 Back
 EXit	 Exit
 Info	 Info
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Red/FTA/CAS	 Red
 Green/SAT	 Green
 Yellow/Tv/SAT	 Yellow





Original		Rechange		Original		Rechange	
	Blue/A/V		Blue				
	↑/+100		>>				
	↓/-100		<<				
	+		>>				
	-		<<				
	F1/Zoom		Eject				
	F2/Sleep		Sleep				
	F3/PIP		3D				
	F4/Recall		Dual				
	[≡]/Text		Text				
	[...]		Subt				

