















































Original		Rechange		Original		Rechange	
	Power		Power		FAV		Pre Ch
	Source		AV		Setup		Options
	Light		Smart		Menu		Menu
	Text		Text		Exit		Exit
	Subt		Subt		Up		Up
	Audio		Dual		Down		Down
	EPG		Guide		Right		Right
	Sat List		List		Left		Left
	IPI		Format		OK		Ok
	<<		<<		V+		Vol +
	Play		Play		V-		Vol -
	Pause		Pause		Mute		Mute
	>>		>>		Info		Info
	I<<		I<<		P+		Ch +
	Stop		Stop		P-		Ch -
	Rec		Rec		Red/Radio		Red
	>>I		>>I		Green/Sleep		Green





Original		Rechange		Original		Rechange	
	Yellow/S/M/D		Yellow				
	Blue/Res		Blue				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	3D		3D				
	Recall		Back				

