















Original	Recharge
 Power	 Power
 Source	 AV
 Vol+	 Vol +
 Vol-	 Vol -
 Play	 Play
 Pause	 Pause
 >	 >>
 <	 <<
 Wireless	 Up
 Wireless	 Down
 Bass+	 Ch +
 Bass-	 Ch -
 Mute	 Mute
 Sound Mode	 Dual
 Bluetooth	 Smart
 Soundshift	 Subt
 Shuffle	 3D

Original	Recharge
 Calibration	 Options
 Night Mode	 Exit
 DIM Display	 Info
 Audio Sync +	 Right
 Audio Sync -	 Left

