



































































































Original	Rechange
 Power	 Power
 Mute	 Mute
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/AV	 0
 Rec	 Rec
 Tv/Radio	 TV/R
 <<<	 <<<
 Stop/DVR	 Stop

Original	Rechange
 Play/Pause	 Play
 >>>	 >>>
 SFI	 Guide
 www	 Media
 ↑	 >>>
 ↓	 <<<
 Recall/Zurück	 Back
 Info/Vor	 Info
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 P+	 Ch +
 P-	 Ch -
 OPT	 Options
 NAV	 List





	Original	Rechange	Original	Rechange
	Vol+	 Vol +		
	Vol-	 Vol -		
	Red	 Red		
	Green	 Green		
	Yellow	 Yellow		
	Blue	 Blue		
	Menu	 Menu		
	♪/Ton	 Dual		
	Timer	 AV		
	Zoom	 Eject		
	TXT	 Text		
	I>/Still	 Pause		
	HDMI	 Smart		
	PIP	 3D		

