





































































Original		Rechange		Original		Rechange	
	Standby		Power		Left		Left
	Login / Lock		Smart		OK		Ok
	1		1		Right		Right
	2		2		Down		Down
	3		3		+		Vol +
	4		4		-		Vol -
	5		5		Record		Rec
	6		6		Stop		Stop
	7		7		Extra		Options
	8		8		<<		<<
	9		9		Play		Play
	0		0		>>		>>
	[]		Info		>>		>>
	Menu		Menu		Green / Audio		Green
	PTZ		Media		Green / Audio		Dual
	Exit		Exit		Red / Mute		Red
	Up		Up				



