


























	Original	Rechange	Original	Rechange
	Power			
	Mute			
	+			
	-			
	Bass			
	(:)			
	AUX In			
	Optical			
	HDMI Tv			
	HDMI 1			
	HDMI 2			
	HDMI 3	