







































































Original	Rechange	Original	Rechange
 Power	 Power	 Play	 Play / Slow
 Mute	 Mute / Dimmer	 Pause	 Pause / Step / Freeze
 Sleep	 Sleep / Timer	 >>	 >> / Tune+
 AV	 AV / Input / RDS	 EPG	 Guide / EPG / -/-
 1	 1	 Up	 Up
 2	 2	 Recall	 Fav / Marker / PC
 3	 3	 I<<	 I<< / Preset-
 4	 4	 Left	 Left
 5	 5	 OK	 OK
 6	 6	 Right	 Right
 7	 7	 >>I	 >>I / Preset+
 8	 8	 Zurück	 Back / Return
 9	 9	 Down	 Down
 Rec	 Rec / Rec Mode	 Info	 Info / Angle
 0	 0	 P+	 CH+ / Page+
 Stop	 Stop / Hold	 Exit	 Exit / Cancel / Clear
 <<	 << / Tune-	 Vol+	 Vol+





Original	Recharge	Original	Recharge
 P-	 CH- / Page-		
 Multimedia	 Display / Media		
 Vol-	 Vol-		
 Red	 Red / Netflix / Search		
 Green	 Green / APP / Repeat		
 Yellow	 Yellow / YouTube / Repeat		
 Blue	 Blue / Prime Video / Random		
 Menü	 Menu / Home		
 Untertitel	 Subtitle / EQ		
 Lang.	 Audio / Lang I/II		
 Ton	 TV/Radio /		
 Zoom	 Zoom / Size		
 TXT	 Text / Goto		
 Internet	 Smart / List		
 FAV	 Shift + Fav / Marker / PC		
 Bildmodus	 Picture / Format		

