







































































Original		Rechange		Original		Rechange	
	Power		Power		Yellow		Yellow
	Mute		Mute		Blue		Blue
	1		1		i		Info
	2		2		Text		Text
	3		3		Up / P+		Up
	4		4		Up / P+		Ch +
	5		5		Down / P-		Down
	6		6		Down / P-		Ch -
	7		7		Right / Vol+		Vol +
	8		8		Right / Vol+		Right
	9		9		Left / Vol-		Vol -
	0 / AV		0		Left / Vol-		Left
	0 / AV		AV		Menu / OK		Menu
	Red / Zoom		Red		Menu / OK		Ok
	Red / Zoom		Eject		[[]]		Stop
	Green / Audio		Green		F.T/L		Smart
	Green / Audio		Dual		[?]		Media

































	Original	Recharge		Original	Recharge
	[⇕]	SHIFT + ZOOM Shift + Eject			
	[⊖]	PROG SLEEP Sleep			
	>	FAV PRE-CH Pre Ch			
	[X]	CLEAR EXIT Exit			
	[≡i]	PICTURE FORMAT Format			




















	Original	Recharge	Original	Recharge
	Power			
	Menu			
	OK			
	Up			
	Down			
	Right			
	Left			
	<<			
	Play			
	>>			
	Stop			
	Rec			
	↑			
	↓			





	Original	Recharge	Original	Recharge
	Power			
	<<			
	Play			
	>>			
	Rec			
	Stop			
	Up			
	Down	