







































































Original		Rechange		Original		Rechange	
	Power		Power		PC		Media
	Source		AV		Vol+		Vol +
	1		1		Vol-		Vol -
	2		2		Mute		Mute
	3		3		P+		Ch +
	4		4		P-		Ch -
	5		5		Menu		Menu
	6		6		Exit		Exit
	7		7		Up		Up
	8		8		Down		Down
	9		9		Right		Right
	0		0		Left		Left
	-/-		Guide		Enter		Ok
	[≡0]/PRE-CH		Pre Ch		[≡+]/PIP		3D
	[ ]/TV		TV/R		[≡?]/Info		Info
	CH MGR		Smart		TTX/MIX		Text
	Sleep		Sleep		Red/P.Mode		Red



