




















	Original	Rechange	Original	Rechange
	Power			
	Vol+			
	Vol-			
	Mute			
	Late Night			
	o dB			
	Test			
	Delay			
	Level			
	Adjustement+			
	Adjustement-			
	Input			
	Bass+			
	Bass-			
	Treble+			
	Treble-			
	Surround Mode	