




































Original	Rechange	Original	Rechange
 Standby	 Power	 SP/LP	 Format
 Timer	 AV	 P+	 Ch +
 Monitor	 Smart	 P-	 Ch -
 1	 1	 Record	 Rec
 2	 2	 <<	 <<
 3	 3	 Play	 Play
 4	 4	 >>	 >>
 5	 5	 >I/Index	 >>I
 6	 6	 Stop	 Stop
 7	 7	 >I</Still	 3D
 8	 8		
 9	 9		
 0	 0		
 Select	 Ok		
 Clear	 Exit		
 System	 Menu		
 Tracking	 Options		

