









Original	Recharge	Original	Recharge
	Power		Power
	Mute		Mute / Dimmer
	-		CH- / Page-
	+		CH+ / Page+
	(:)		D.Menu / Top
	Bass		Sound / Title
	Source		AV / Input / RDS

