







































































Original	Rechange	Original	Rechange
 Power	 Power	 Yellow	 Yellow
 1	 1	 Blue	 Blue
 2	 2	 Guide	 Guide
 3	 3	 Rec List	 List
 4	 4	 Input	 AV
 5	 5	 *	 Menu
 6	 6	 Back	 Back
 7	 7	 TV	 TV/R
 8	 8	 Home	 Smart
 9	 9	 Up	 Up
 0	 0	 Down	 Down
 [i+]	 Info	 Right	 Right
 [=]	 Text	 Left	 Left
 Google Play	 Media	 OK	 Ok
 Netflix	 Shift + Media	 Vol+	 Vol +
 Red	 Red	 Vol-	 Vol -
 Green	 Green	 Mute	 Mute



