














































































































































Original	Recharge	Original	Recharge
 Power	 Power	 Stop	 Stop
 Open / Close	 Eject	 Vol-	 Vol -
 CD	 Green	 Vol+	 Vol +
 TUNER	 Red	 1	 1
 USB / MP3 LINK	 Yellow	 2	 2
 TAPE	 Blue	 3	 3
 Up	 Up	 4	 4
 Left / I<<	 Left	 5	 5
 Left / I<<	 I<<	 6	 6
 Play/Pause	 Pause	 7	 7
 Play/Pause	 Play	 8	 8
 Play/Pause	 Ok	 9	 9
 Right / >>I	 Right	 0	 0
 Right / >>I	 >>I	 Prog	 Sleep
 Down	 Down	 Sleep / Timer	 AV
 Display / RDS	 Info	 DSC	 Smart
 Mute	 Mute	 DBB	 Media









































































Original	Recharge	Original	Recharge
 Power	 Power	 Stop	 Stop
 Open / Close	 Eject	 Vol-	 Vol -
 CD	 Green	 Vol+	 Vol +
 TUNER	 Red	 1	 1
 USB / MP3 LINK	 Yellow	 2	 2
 TAPE	 Blue	 3	 3
 Up	 Up	 4	 4
 Left / I<<	 I<<	 5	 5
 Left / I<<	 Left	 6	 6
 Play / Pause	 Play	 7	 7
 Play / Pause	 Pause	 8	 8
 Play / Pause	 Ok	 9	 9
 Right / >>I	 Right	 0	 0
 Right / >>I	 >>I	 Prog	 Sleep
 Down	 Down	 Repeat / Shuffle	 Text
 Display / RDS	 Info	 Sleep / Timer	 AV
 Mute	 Mute	 DSC	 Smart

Original	Recharge	Original	Recharge
 Power	 Power	 Stop	 Stop
 Open / Close	 Eject	 Vol-	 Vol -
 CD	 Green	 Vol+	 Vol +
 TUNER	 Red	 1	 1
 USB / MP3 LINK	 Yellow	 2	 2
 TAPE	 Blue	 3	 3
 Up	 Up	 4	 4
 Left / I<<	 I<<	 5	 5
 Left / I<<	 Left	 6	 6
 Play / Pause	 Play	 7	 7
 Play / Pause	 Pause	 8	 8
 Play / Pause	 Ok	 9	 9
 Right / >>I	 Right	 0	 0
 Right / >>I	 >>I	 Prog	 Sleep
 Down	 Down	 Repeat / Shuffle	 Text
 Display / RDS	 Info	 Sleep / Timer	 AV
 Mute	 Mute	 DSC	 Smart





Original	Rechange	Original	Rechange
 Power	 Power	 Stop	 Stop
 Open/Close	 Eject	 Vol-	 Vol -
 CD	 Green	 Vol+	 Vol +
 TUNER	 Red	 1	 1
 USB / MP3 LINK	 Yellow	 2	 2
 TAPE	 Blue	 3	 3
 Up	 Up	 4	 4
 Left	 Left	 5	 5
 I<<	 I<<	 6	 6
 Ok	 Ok	 7	 7
 Pause	 Pause	 8	 8
 Play	 Play	 9	 9
 >>I	 >>I	 0	 0
 Right	 Right	 Prog	 Options
 Down	 Down	 Repeat/Shuffle	 Text
 RDS/Display	 Info	 Sleep/Timer	 Sleep
 Mute	 Mute	 DSC	 Smart






Original

	DBB

Recharge

	Media

Original

Recharge





Original		Recharge		Original		Recharge	
	Power		Power		Sleep		Sleep
	CD		Red		DSC		Media
	TUNER		Green		DBB		Smart
	USB / MP3 LINK		Yellow				
	TAPE		Blue				
	I<		I<<				
	<<		<<				
	Play/Pause		Play				
	Play/Pause		Pause				
	>I		>>I				
	>>		>>				
	Mute		Mute				
	Stop		Stop				
	Vol-		Vol -				
	Vol+		Vol +				
	Repeat		Text				
	Shuffle		TV/R				

